

FIG.1A




FIG. 1B




FIG. 1C




FIG.2



FIG.3A




FIG.3B






FIG.4

(a)



(b)



(c)




FIG.5




FIG.6




FIG.7A




FIG.7B




FIG.7C




FIG.8




FIG.9A




FIG.9B




FIG.9C




FIG. 10A




FIG. 10B




FIG. 10C





FIG.11A



TOUCH

FIG.11B




FIG.11C






FIG.12A



TOUCH

FIG.12B



PRESS

FIG.12C

CANCEL

PUT YOUR CASH OR CARD INTO THE MACHINE

TICKET	TO OGIKUBO
AMOUNT OF PURCHASE MONEY	¥160
AMOUNT OF MONEY PUT INTO THE MACHINE	¥0

③

FIG.13




FIG.14A




FIG.14B




FIG.15A




FIG.15B




FIG.16




FIG.17A




FIG.17B




FIG.17C




FIG.18




FIG.19




FIG.20A




FIG.20B




FIG.21




FIG.22




FIG.23




FIG.24




FIG.25

